

Bona Cleaner

Concentrated detergent for cleaning of finished wood and cork floors.



Bona Cleaner is a highly concentrated, slightly alkaline cleaner specifically designed for the cleaning of finished wood and cork floors. Bona Cleaner can be used for regular mopping or in a machine-based cleaning program.

- Specifically designed for lacquered wood and cork floors
- Efficient, low-foaming formula
- Leaves no dulling residue
- For daily maintenance and regular cleaning

TECHNICAL DATA

| pH-value: | Concentrate ca. 11 |
|--|--|
| Base: | Solution of synthetic soaps |
| Dilution: | Normal cleaning: 0.5 dl to 5 liters of water (1%) |
| | Heavily soiled floors: 1 dl to 5 liters of water (2%) |
| Application tools: | Bona Cleaning Pad, cotton cloth, cleaning mop |
| Shelf life: | At least 2 years, from the date of production, in |
| | unopened original container |
| Storage/Transport: | The temperature must not fall below +5°C or exceed +25°C during |
| | storage and transport. |
| Disposal: | Wastes and emptied containers should be handled in accordance with |
| | local regulations. |
| Pack size: | 3 x 5 liters (44 boxes per pallet) |
| | 10 x 1 liters (50 boxes per pallet) |
| Additional detailed information is noted in the appropriate Safety Data Sheet. | |

1



Bona Cleaner

Concentrated detergent for cleaning of finished wood and cork floors.

PREPARATIONS

Remove loose dust/grit etc. using a vacuum cleaner, scissor mop or other dry-cleaning method.

APPLICATION

Dilute concentrate according to recommendation and clean the floor using a mop or an auto scrubber equipped with a white or tan pad. Note that excessive use of water may damage the floor. Always keep the amount of water used to clean to a minimum and be careful where the floor has open gaps. Replace the cleaning water periodically to avoid streaking.

AUTO SCRUBBER

Recommendations for use of auto scrubber:

- 1. Always fill the tank with clean water prior to use.
- 2. Run the machine along, never across, the parquet boards.
- 3. Water loss from the machine must not exceed 1 lit/100 m². Test by adding 10 liters of water to the tank and check the remaining water after 100 m² (e.g. 5 x 20 m). 9 liters should remain in the tank.
- 4. Water should be removed promptly, make sure not to leave puddles when turning with the machine.
- 5. If distributing water with the machine, the water must be removed within 3 minutes.
- 6. Keep the rubber band clean and in good trim. Replace annually or if the machine is leaving puddles or too much water.
- 7. Do not use aggressive pads on the surface. Aggressive pads may scratch and wear on the surface. The milder the pad, the lesser the wear.

